



WARNING

- *Risk of shock,do not plug in the unit before assembly is complete.
- *Do not exceed the maximum wattage rating.(Max. 150W).
- *Before turning on, please follow the instruction manual step by step.

INSTALLATION

- 1. Slide the two bushings on harp (C) up to expose the flat ends at the bottom.
- Insert the flat ends of harp (C) into the saddle (B). Slide the two bushings down to secure the harp (C) onto saddle (B).
- 3. Install a light bulb(bulb type E26 13W(MED BASE)) into lamp holder (Type A).
- 4. Place the center ring of shade (D) onto the threaded end of the harp (C). Use the finial (E) to secure the shade (D) onto the harp (C).
- 5. Adjust the shade until it is leveled horizontally.

IMPORTANT SAFETY INSTRUCTIONS

1. This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless the plug can be fully inserted. Do not change or alter the plug.

IN AN ONGOING EFFORT TO BE ENVIROMENTALLY FRIENDLY AND IN COMPLIANCE WITH CALIFORNIA TITLE 20 AN ENERGY SAVING COMPACT FLUORESCENT BULB(S) IS INCLUDED. PLEASE NOTE THAT THE LIFE EXPECTANCY OF THE BULB(S) IS NOT GUARANTEED.



